



29L MICROWAVE OVEN 900W



INSTRUCTION MANUAL EM9P032RM

AFTER SALES SUPPORT

0800 422 274

CONTENT

PRECAUTIONS TO AVOID POSSIBLE EXPOSURE

TO EXCESSIVE MICROWAVE ENERGY..... 4

IMPORTANT SAFETY INSTRUCTIONS WARNING.....5

WARNING 8

CLEANING9

UTENSILS10

OVERVIEW OF OVEN PARTS AND ACCESSORIES.....12

TURNTABLE INSTALLATION.....13

INSTALLATION.....14

CONTROL PANEL 15

OPERATION.....16

TROUBLE SHOOTING.....21

WARRANTY.....22

Read these instructions carefully before using your microwave oven, and them for future reference.

If you follow the instructions, your oven will provide you with many years of good service.

SAVE THESE INSTRUCTIONS CAREFULLY

PRECAUTIONS TO AVOID POSSIBLE EXPOSURE TO EXCESSIVE MICROWAVE ENERGY

- (a) Do not attempt to operate this oven with the door open since this can result in harmful exposure to microwave energy. It is important not to break or tamper with the safety interlocks.
- (b) Do not place any object between the oven front face and the door or allow soil or cleaner residue to accumulate on sealing surfaces.
- (c) **WARNING:** If the door or door seals are damaged, the oven must not be operated until it has been repaired by a competent person.

ADDENDUM

If the apparatus is not maintained in a good state of cleanliness, its surface could be degraded and affect the lifespan of the apparatus and lead to a dangerous situation.

SPECIFICATIONS

Model	EM9P032RM
Rated Voltage/Frequency	230-240 V~ 50 Hz
Microwave Input	1400 W
Microwave Output	900 W
Oven Capacity	29L
Turntable Diameter	Ø288mm
External Dimensions	495x396x290mm
Net Weight	Approx. 13.34kg

IMPORTANT SAFETY INSTRUCTIONS WARNING

To reduce the risk of fire, electric shock, injury to persons or exposure to excessive microwave oven energy when using your appliance, follow basic precautions, including the following:

1. Read and follow the specific: "PRECAUTIONS TO AVOID POSSIBLE EXPOSURE TO EXCESSIVE MICROWAVE ENERGY".
2. This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
3. Children should be supervised to ensure that they do not play with the appliance.
4. If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
5. WARNING: Ensure that the appliance is switched off before replacing the lamp to avoid the possibility of electric shock.
6. WARNING: It is hazardous for anyone other than a competent person to carry out any service or repair operation that involves the removal of a cover which gives protection against exposure to microwave energy.
7. WARNING: Liquids and other foods must not be heated in sealed containers since they are liable to explode.
8. When heating food in plastic or paper containers, keep an eye on the oven due to the possibility of ignition.

9. Only use utensils that are suitable for use in microwave ovens.
10. If smoke is observed, switch off or unplug the appliance and keep the door closed in order to stifle any flames.
11. Microwave heating of beverages can result in delayed eruptive boiling, therefore care must be taken when handling the container.
12. The contents of feeding bottles and baby food jars shall be stirred or shaken and the temperature checked before consumption, in order to avoid burns.
13. Eggs in their shell and whole hard-boiled eggs should not be heated in microwave ovens since they may explode, even after microwave heating has ended.
14. The oven should be cleaned regularly and any food deposits removed.
15. Failure to maintain the oven in a clean condition could lead to deterioration of the surface that could adversely affect the life of the appliance and possibly result in a hazardous situation.
16. The appliance must not be installed behind a decorative door in order to avoid overheating.
17. The microwave oven shall not be placed in a cabinet unless specified clearances from all sides are maintained.
18. This appliance is intended to be used in household and similar applications such as:
 - staff kitchen areas in shops, offices and other working environments;
 - by clients in hotels, motels and other residential type environments;
 - farm houses;
 - bed and breakfast type environments.

19. The microwave oven is intended for heating food and beverages. Drying of food or clothing and heating of warming pads, slippers, sponges, damp cloth and similar may lead to risk of injury, ignition or fire.
20. Metallic containers for food and beverages are not allowed during microwave cooking.
21. The appliance shall not be cleaned with a steam cleaner.
22. The appliance is intended to be used freestanding.
23. The rear surface of appliances shall be placed against a wall.
24. Ensure the waveguide cover is kept clean by gently wiping its surface with a damp cloth to remove food or liquid contaminants. Failure to maintain can result in permanent damage resulting in sparking / burning of the cover during subsequent use. Should this occur, switch off immediately.

**READ CAREFULLY AND KEEP FOR FUTURE
REFERENCE**

**HOUSEHOLD USE ONLY
(NOT FOR COMMERCIAL USE)**

TO REDUCE THE RISK OF INJURY TO PERSONS GROUNDING INSTALLATION

DANGER

Electric Shock Hazard

Touching some of the internal components can cause serious personal injury or death. Do not disassemble this appliance.

WARNING

Electric Shock Hazard

Improper use of the grounding can result in electric shock.

Do not plug into an outlet until appliance is properly installed and grounded.

This appliance must be grounded. In the event of an electrical short circuit, grounding reduces the risk of electric shock by providing an escape wire for the electric current.

This appliance is equipped with a cord having a grounding wire with a grounding plug. The plug must be plugged into an outlet that is properly installed and grounded.

Consult a qualified electrician or serviceman if the grounding instructions are not completely understood or if doubt exists as to whether the appliance is properly grounded.

If it is necessary to use an extension cord, use only a 3-wire extension cord.

1. A short power-supply cord is provided to reduce the risks resulting from becoming entangled in or tripping over a longer cord.
2. If a long cord set or extension cord is used:
 - 1) The marked electrical rating of the cord set or extension cord should be at least as great as the electrical rating of the appliance.
 - 2) The extension cord must be a grounding-type 3-wire cord.
 - 3) The long cord should be arranged so that it will not drape over the counter top or tabletop where it can be pulled on by children or tripped over unintentionally.

CLEANING

Be sure to unplug the appliance from the power supply.

1. Clean the cavity of the oven after using with a slightly damp cloth.
2. Clean the accessories in the usual way in soapy water.
3. The door frame and seal and neighbouring parts must be cleaned carefully with a damp cloth when they are dirty.
4. Do not use harsh abrasive cleaners or sharp metal scrapers to clean the oven door glass since they can scratch the surface, which may result in shattering of the glass.
5. Cleaning Tip---For easier cleaning of the cavity walls that the food cooked can touch: Place half a lemon in a bowl, add 300ml (1/2 pint) water and heat on 100% microwave power for 10 minutes. Wipe the oven clean using a soft, dry cloth.

WARNING: Failure to regularly clean and maintain surfaces inside the oven cavity (in particular the waveguide cover and surface immediately adjacent), will increase the risk of premature product failure. Use a damp cloth to gently wipe the waveguide cover after heavy use or in case of food / liquid spillage onto its surface. Contaminants that are not cleaned from the waveguide cover will cause increased heating and risk of insulation break down during subsequent use. **This can cause visible sparking / burning of the waveguide cover during use.** If this occurs, switch off immediately. The microwave will require replacement of the waveguide cover and safety checks by a qualified service person before subsequent use.

UTENSILS

CAUTION

Personal Injury Hazard

It is hazardous for anyone other than a competent person to carry out any service or repair operation that involves the removal of a cover which gives protection against exposure to microwave energy.

See the instructions on "Materials you can use in microwave oven or to be avoided in microwave oven." There may be certain non-metallic utensils that are not safe to use for microwaving. If in doubt, you can test the utensil in question following the procedure below.

Utensil Test:

1. Fill a microwave-safe container with 1 cup of cold water (250ml) along with the utensil in question.
2. Cook on maximum power for 1 minute.
3. Carefully feel the utensil. If the empty utensil is warm, do not use it for microwave cooking.
4. Do not exceed 1 minute cooking time.

Materials you can use in microwave oven


Utensils	Remarks
Browning dish	Follow manufacturer's instructions. The bottom of browning dish must be at least 3/16 inch (5mm) above the turntable. Incorrect usage may cause the turntable to break.
Dinnerware	Microwave-safe only. Follow manufacturer's instructions. Do not use cracked or chipped dishes.
Glass jars	Always remove lid. Use only to heat food until just warm. Most glass jars are not heat resistant and may break.
Glassware	Heat-resistant oven glassware only. Make sure there is no metallic trim. Do not use cracked or chipped dishes.
Oven cooking bags	Follow manufacturer's instructions. Do not close with metal tie. Make slits to allow steam to escape.
Paper plates and cups	Use for short-term cooking/warming only. Do not leave oven unattended while cooking.
Paper towels	Use to cover food for reheating and absorbing fat. Use with supervision for a short-term cooking only.
Parchment paper	Use as a cover to prevent splattering or a wrap for steaming.
Plastic	Microwave-safe only. Follow the manufacturer's instructions. Should be labeled "Microwave Safe". Some plastic containers soften, as the food inside gets hot. "Boiling bags" and tightly closed plastic bags should be slit, pierced or vented as directed by package.
Plastic wrap	Microwave-safe only. Use to cover food during cooking to retain moisture. Do not allow plastic wrap to touch food.
Thermometers	Microwave-safe only (meat and candy thermometers).
Wax paper	Use as a cover to prevent splattering and retain moisture.

Materials to be avoided in microwave oven


Utensils	Remarks
Aluminum tray	May cause arcing. Transfer food into microwave-safe dish.
Food carton with metal handle	May cause arcing. Transfer food into microwave-safe dish.
Metal or metal-trimmed utensils	Metal shields the food from microwave energy. Metal trim may cause arcing.
Metal twist ties	May cause arcing and could cause a fire in the oven.
Paper bags	May cause a fire in the oven.
Plastic foam	Plastic foam may melt or contaminate the liquid inside when exposed to high temperature.
Wood	Wood will dry out when used in the microwave oven and may split or crack.

OVERVIEW OF OVEN PARTS AND ACCESSORIES


Remove the oven and all materials from the carton and oven cavity. Your oven comes with the following accessories:




Glass Tray



Turntable Ring Assembly



Instruction Manual



- A) Safety interlock system
- B) Observation window
- C) Door assembly


- D) Oven cavity
- E) Turntable ring assembly
- F) Control panel
- G) Waveguide Cover

Note 1: See important Warning relating to Waveguide Cover - Cleaning, earlier in this manual.

Note 2: Images are representative only and may differ from actual product.


TURNTABLE INSTALLATION

Cleaning the cooking compartment and putting the turntable in place. For new installations, make sure all packaging and shipping tape has been removed. Before using the appliance to prepare food for the first time, you will need to put the turntable in place correctly. You must clean the cooking compartment and accessories.



1) Glass Tray

2) Turntable Ring Assembly



Notes :

1. Never use the appliance without the turntable. Make sure that it is properly engaged. The turntable can turn clockwise or anti-clockwise.
2. Never place the glass tray upside down. The glass tray should never be restricted.
3. Both glass tray and turntable ring assembly must always be used during cooking.
4. All food and containers of food are always placed on the glass tray for cooking.
5. Never restrict the movement of the turntable.
6. If glass tray or turntable ring assembly cracks or breaks, contact your nearest authorized service center.


Countertop Installation

Remove all packing material and accessories. Examine the oven for any damage such as dents or broken door. Do not install if oven is damaged.

Cabinet: Remove any protective film found on the microwave oven cabinet surface. Do not remove the waveguide cover that is attached to the oven cavity to protect the magnetron.

Installation

1. Select a level surface that provide enough open space for the intake and/or outlet vents.



(1) The minimum installation height is 85cm.

(2) The rear surface of appliance shall be placed against a wall.

Leave a minimum clearance of 30cm above the oven, a minimum clearance of 20cm is required between the oven and any adjacent walls.

(3) Do not remove the legs from the bottom of the oven.

(4) Blocking the intake and/or outlet openings can damage the oven.

(5) Place the oven as far away from radios and TV as possible. Operation of microwave oven may cause interference to your radio or TV reception.

2. Plug your oven into a standard household outlet. Be sure the voltage and the frequency is the same as the voltage and the frequency on the rating label.

WARNING: Do not install oven over a range cooktop or other heat-producing appliance. If installed near or over a heat source, the oven could be damaged and the warranty would be void.

The accessible surface may be hot during operation.



CONTROL PANEL

Time Cook	Time Defrost	Weight Defrost
Power	Clock	Kitchen Timer

Popcorn	Potato	Pizza
Frozen Vegetable	Beverage	Dinner Plate

Express Cook 1-6min

1	2	3
4	5	6
7	8	9

<u>STOP</u> CANCEL	0	<u>START</u> +30SEC.
------------------------------	---	--------------------------------

OPERATION

1. Setting the Clock

(1) Press **Clock** once and then "00:00" will display.

(2) Press the number keys to enter the time.

Example: To set the clock to 12:30, please press "1, 2, 3, 0" in turn.

(3) Press **Clock** to confirm. The clock is set.

Notes:

(1) To reset the clock, please repeat step 1 to step 3.

(2) The clock is a 12-hour display. If the clock is not set, it will not work when powered.

2. Setting the Kitchen Timer

(1) Press **Kitchen Timer** once and then "00:00" will display.

(2) Press the number keys to set the desired time. The maximum time value is "99:99".

(3) Press **START**
+30SEC. to confirm. The timer starts counting down.

Note: The kitchen timer is a timer.

3. Microwave Cooking

10 power levels are available.

Power	100%	90%	80%	70%	60%	50%	40%	30%	20%	10%	0%
Display	PL10	PL9	PL8	PL7	PL6	PL5	PL4	PL3	PL2	PL1	PL0

(1) Press **Power** once and then "PL10" will display.

(2) Press the number keys to set the power level. The 10 power levels are available.

(3) Press **START**
+30SEC. to confirm.

(4) Press **Time Cook** once and then "00:00" will display.

(5) Press the number keys to set the cooking time. The maximum time value is "99:99".

(6) Press **START**
+30SEC. to start cooking.

Notes:

(1) In the process of setting, if **STOP**
CANCEL is pressed or if there is no operation within 1 minute, the setting is invalid.

(2) The power level can be changed during operation. Press **Power** once and then the current power will display for three seconds. Press the number keys to change the power. The oven will work with the selected power.

4. Defrost by Weight

(1) Press **Weight**
Defrost once and then the screen will display "dEF1".

(2) Press the number keys to set the weight of the food. The range of weight is 100~ 2000g.

(3) Press **START**
+30SEC. to start defrosting.

Note: The buzzer will sound to remind you to turn the food over during defrosting.

If no operation, the oven will continue working.

5. Defrost by Time

(1) Press **Time**
Defrost once and then the screen will display "dEF2".

(2) Press the number keys to set the desired defrosting time.

The maximum time value is "99:99".

(3) Press **START**
+30SEC. to start defrosting.

Note: The default power level is PL3 and it cannot be changed.

6. Speedy Cooking

- (1) In standby mode, pressing the number keys 1 to 6 lets you quickly select a cooking time from 1 to 6 minutes. Then you can press **START** +30SEC. to increase the cooking time. The maximum time value is "99:99".
- (2) In standby mode, pressing **START** +30SEC. once to cook food at 100% power level for 30 seconds. Each press on the same key can increase 30 seconds and the maximum time value is "99:99".

Note: In the microwave cooking and defrost by time cooking state, each one more press on **START** +30SEC. can increase the cooking time by 30 seconds. (Except the defrost by weight and auto menu.)

7. Multi-Stage Cooking

Notes: (1) Two cooking stages can be set in multi-stage cooking.

(2) If you set the defrost function, it will work automatically in the first stage.

(3) The auto menu and kitchen timer cannot be set as one of the multi-stage.

Example: Defrost food for 300g and then cook with 50% microwave power for 7 minutes.

- (1) Press **Weight Defrost** once and then the screen will display "dEF1".
- (2) Press "3", "0", and "0" to set the weight of the food to 300g.
- (3) Press **Power** once and then "PL10" will display.
- (4) Press "5" to set the power level to PL5.
- (5) Press **START** +30SEC. to confirm.
- (6) Press **Time Cook** once and then "00:00" will display.
- (7) Press "7", "0", and "0" to set the cooking time to 7 minutes.
- (8) Press **START** +30SEC. to start cooking.

8. Auto Menu

(1) Press the corresponding menu key repeatedly to choose the weight of the food you want to cook.

Example: Press **Pizza** twice and then “200” displays.

(2) Press **START**
+30SEC. to start cooking.

Auto Menu Chart

Menu	Weight	Display	Power
Pizza	100g	100	PL8
	200g	200	
	400g	400	
Popcorn	50g	50	PL10
	100g	100	
Potato	1	1	
	2	2	
	3	3	
Frozen Vegetable	200g	200	
	300g	300	
	400g	400	
Beverage	1 cup(120ml)	1-	
	2 cups(240ml)	2-	
	3 cups(360ml)	3-	
Dinner Plate	200g	200	
	400g	400	

9. Lock Function for Children

You can use this function to disable the screen buttons and prevent your child from accidentally turning the oven on.

To activate the lock:

In standby mode, press and hold **STOP**
CANCEL for three seconds. A beep sounds and " [] " will display.

To deactivate the lock:

In the locked state, press and hold **STOP**
CANCEL for three seconds. A beep sounds.

10. Mute mode

To activate the mute mode:

In standby mode, press and hold "8" for three seconds. The buzzer will sound.

When you press the key, it does not make a sound.

To deactivate the mute mode:

In mute mode, press and hold "8" for three seconds. The buzzer will sound.

11. Inquiring Function

- (1) If the clock has been set, the current time will display for three seconds by pressing **Clock** in the cooking state.
- (2) In the microwave cooking state, press **Power** to inquire about the power level. It will display for three seconds.

Trouble shooting

Normal	
Microwave oven interfering TV reception	Radio and TV reception may be interfered when microwave oven operating. It is similar to the interference of small electrical appliances, like mixer, vacuum cleaner, and electric fan. It is normal.
Dim oven light	In low power microwave cooking, oven light may become dim. It is normal.
Steam accumulating on door, hot air out of vents	In cooking, steam may come out of food. Most will get out from vents. But some may accumulate on cool place like oven door. It is normal.
Oven started accidentally with no food in.	It is forbidden to run the unit without any food inside. It is very dangerous.

Trouble	Possible Cause	Remedy
Oven cannot be started.	(1) Power cord is not plugged in tightly.	Unplug. Then plug again after 10 seconds.
	(2) Fuse blowing or circuit breaker works.	Replace fuse or reset circuit breaker (repaired by professional personnel of our company)
	(3) Trouble with outlet.	Test outlet with other electrical appliances.
Oven does not heat.	(4) Door is not closed well.	Close door well.



12 MONTH WARRANTY

Your Living&Co product has been inspected and tested and is guaranteed subject to the following for a period of 12 months from the date of purchase against defects in workmanship and materials. During this period, such defects will be rectified by repair or replacement of the product purchased. Your product contains no user serviceable components and this warranty becomes invalid if in our opinion the product has been misused, abused, incorrectly installed, tampered with, connected to an electrical supply not corresponding with the name plate specification, or subjected to power surges. The warranty does not include any labour or other associated expense that may be involved in removal or installation of the product. Normal wear and tear is expressly excluded.

If your Living&Co product fails to operate satisfactorily, please return it to the retailer from whom it was purchased. To obtain a repair or replacement product under this warranty, you will need to produce satisfactory evidence of date of purchase. The completed warranty and purchase receipt must be presented with the product. The warranty should be filled out at the time of purchase. It is in your interest to make sure this is done.

If the product is to be replaced (cannot be repaired) then that replacement will be of the faulty product or accessory excluding packaging, instruction card etc. Where a replacement product is supplied, this shall be guaranteed for the balance of the original warranty period. Any model that is no longer available will be replaced by a model of a value and with such features as we consider appropriate in the circumstances. Living&Co is not responsible for freight forwarding charges, losses or damage in transit.

If service is required after the warranty period has expired, the product should be returned to a qualified electrical technician. Service outside of the warranty period will be at your cost.

Consumers Guarantee Act (1993).

In accordance with the above act consumers are advised that: The manufacturer does not undertake that repair facilities and parts are necessarily available for this product.

If any of the provisions of the foregoing are contrary to any relevant legislation, then that provision shall be deemed to be excluded from the warranty and the rest of the provisions will continue to apply.

IMPORTANT: PLEASE RETAIN THIS WARRANTY CARD

NAME: _____

ADDRESS: _____

PURCHASED FROM: _____

SUBURB: _____

DATE OF PURCHASE: _____

NAME OF PRODUCT: _____

MODEL No: _____

Made In China. Marketed By: The Warehouse, 26 The Warehouse Way, Northcote,
Auckland 0627, 0800 422 274



Warranty

We pride ourselves on producing a range of quality home appliances that are both packed with features and completely reliable. We are so confident in our products, we back them up with a 1 year warranty.

Now you too can relax knowing that you are covered.

Customer Helpline NZ: 0800 422 274

This Product is covered by 1 year warranty when accompanied by proof of purchase.