2018048订单说明书 尺寸142X210MM，105克双铜纸 8个P装订

LIVING&CO®

HOT PLATE

INSTRUCTION MANUAL

CONTENTS

03 IMPORTANT SAFEGUARDS
04 IMPORTANT SAFEGUARDS(Cont.)
05 PARTS DESCRIPTION
06 USING THE HOT PLATE
07 CLEANNING&STORAGE

IMPORTANT SAFEGUARDS

When using electrical appliances, basic safety precautions should always be followed, including the following:

1. Read all instructions carefully before use. Keep this manual for future reference.
2. Never operate the appliance with wet hands.
3. This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
4. Young children should be supervised to ensure they do not play with the appliance. Close supervision is necessary when any appliance is used by or near children.
5. Never let the power cord hang over the edge of a counter of table, or touch hot surfaces.
6. Always use the appliance on a stable level surface and close to a power socket.
7. Always turn the temperature control knob to minimum setting and disconnect from the power outlet when not in use and before cleaning.
8. Always remove the plug from the power socket to disconnect. Do not pull the plug out by the cord.
9. If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
10. Do not dismantle and repair the appliance by yourself. DANGER OF AN ELECTRIC SHOCK!
11. Never operate the appliance after it malfunctions, or if it has been damaged in any manner. Dispose of or have it repaired by qualified personnel.
12. Always ensure that food is cooked in a pan or saucepan, do not attempt to cook food directly on the hot plate.
13. Always ensure that the cookware used on the hot plate does not project beyond the area of the hot plate or overhang the controls.
14. The appliance is intended for household use only. Do not use outdoors or for commercial purpose .Any other use will void the warranty.
15. To protect against risk of electrical hazards, do not immerse the appliance power cord or plug in water or any other liquids.

IMPORTANT SAFEGUARDS (Cont.)

16. Never leave this appliance unattended during use.
17. Never touch the housing and hot plates when in use, as they get hot and may cause injury.
18. Never leave oil or fat that is being heated unattended. This is a fire risk.
19. Never operate the appliance by means of an external timer or separate remote-control system.
20. Do not place on or near a hot gas or electric burner.
21. Do not use an extension cord with this appliance.
22. Do not allow this appliance to touch curtains, wall coverings, clothing ,dish towels or other flammable material during use.
23. Do not operate the appliance inside appliance cabinet or under a wall cabinet when storing In an appliance cabinet always unplug the unit from an electrical power outlet and ensure the Appliance has completely cooled down.

    CAUTION: Hot surface. Care must be taken. The surfaces are liable to get hot during use.

24. Only plug the appliance into 230V~50Hz electrical power outlet.

    WARNING: If the surface is cracked, switch OFF the appliance to avoid the possibility of Electric shock.

PARTS DESCRIPTION

LHP1W

1. Hotplate surface 1500W
2. Power ON indicator light
3. Variable temperature control

Specifications:

Model Number:	LHP1W
Rated Voltage:	240VAC
Rated Power:	1500W

LHP2W

1. Hotplate surface 1400W
2. Hotplate surface 1000W
3. Power ON indicator light
4. Variable temperature control

Model Number:	LHP2W
Rated Voltage:	240VAC
Rated Power:	1400W+1000W

USING THE HOT PLATE

IMPORTANT: When using your Hot Plate for the first time:

- **REMOVE THE WARNING LABEL.**
- **Turn the temperature control to the highest setting for 3 to 5 minutes to condition the protective coating.**

*****The hotplate may give of vapors for up to 15 minutes. This is due to the protective coating on the heating elements. There is no need for concern and the vapors will dissipate with use.*****

This should be the only time the Hot Plate is turned on without any cookware and should be carried out in a well ventilated, controlled environment.

1. Place the appliance on a flat, dry heat resistant surface.
2. Switch "ON" the Hot Plate by turning the temperature control to the required temperature. When the indicator light illuminates, the Hot Plate is in use.
3. Turn the temperature control to achieve the desired temperature of any of the mentioned settings.
   L (Low) : For simmering delicate foods, thickening sauces and slow cooking
   M (Medium) : For simmering large quantities and shallow frying
   H (High) : Rapid heating and boiling
3. When not in use, make sure the temperature control is in the lowest setting position and mains plug is removed from the mains supply.

Note: the lowest setting is not OFF. Please remove the power cord for complete mains disconnection.

4. The indicator light will switch off when the Hot Plate reaches the selected temperature.

Note: Some requirements for the cookware when using the Hot Plate.

a) For the most efficient use of the Hot Plate the cookware used should have a solid base with a diameter no larger than the hotplates
b) Cookware with a base diameter smaller than the diameter of the Hot Plate should not be used.
c) Cookware with convex, concave or uneven bottoms should not be used.

CLEANING

- Disconnect the mains plug of the Hot Plate from the mains supply when not in use.
- Do not immerse the Hot Plate in any liquid.
- Clean the dirty surface with a soft, damp cloth and mild detergent.
- Cooking spills on the Hot Plate can be removed with a household cleaner.

STORAGE

- Store the Hot Plate after it has cooled down.
- When not in use, store the Solid Double Hot Plate in a safe, dry place, out of reach of children.

WARNING

- The temperature of accessible surfaces may be hot when the appliance is operating.
- Do not use this appliance with an external timer or separate remote control system.
- Position the appliance at a minimum distance of 20cm away from walls, curtains and other heat or steam sensitive materials and provide adequate space above and on all sides for air circulation.
- Hotplates after being switched off continue to radiate residual heat for a period of time.
- No more than 5 litres of water can be boiled at any time – It is recommended to use a lid whilst boiling water.

LIVING&CO®

Warranty

We pride ourselves on producing a range
of quality home appliances that are both packed with features
and completely reliable. We are so confident in our products,
we back them up with 3 years warranty.
Now you too can relax knowing that you are covered.

Customer Helpline NZ: 0800 422 274
This Product is covered by 3 years warranty when
accompanied by proof of purchase.