



ROWAN TABLE LAMP

Instructions

Please read these instructions and warnings carefully before operating to ensure safe and satisfactory operation of this product.

Please also retain these instructions for future use.

Warnings:

- This is a Class II product and does not require an earth connection.
- Always use the correct type and wattage of bulb.
- When changing a bulb, always switch off the light at the wall socket and allow the bulb to cool down before handling.
- Dispose of old bulbs carefully.
- Do not switch on the light until the installation is complete.
- Do not cover the lamp or bulb during use as this could be a potential safety hazard.
- The luminaire is not intended for use by children unless suitable adult supervision is provided.
- Children should be supervised to ensure they do not play with the luminaire.
- The fitting is intended for indoor use only.
- If the external flexible cable or cord of this luminaire is damaged, it shall be exclusively replaced by the manufacturer or his service agent or a similar qualified person in order to avoid a hazard.
- To prevent damage to the mains cord, do not let it pass over sharp corners, edges or hot surfaces.
- This lamp should only be used on a flat and stable surface.
- This lamp is not intended for use by persons with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance, by a person responsible for their safety.
- Never touch the bare bulb with your bare fingers or hands.
- Grease or oil from fingers can damage the bulb and cause the bulb to burn out, reduce its operating life, or for halogen bulbs explode. It is recommended to use soft cloth or facial tissue when handling the bulb.

CAUTION: Ensure that the light bulb is not within the recommended 0.5m of any surface when operating as this could be a potential safety hazard.

CAUTION: Never exceed the bulb wattage stated.

WARNING: TAKE CARE NOT TO OVERTIGHTEN THE BULB. THIS SHOULD BE FULLY INSERTED BUT DOES NOT NEED TO BE FORCEFULLY TIGHTEND. LED BULBS CAN BE EASILY DAMAGED WHICH COULD RESULT IN COLLAPSING OF THE LAMP CAP AND SHORT CIRCUIT.

Assembly:

1. Remove protective plastic overwrap from the lamp shade.
2. Remove the threaded plastic shade ring (retaining nut) from the lamp holder.
3. Install the lamp shade onto the lamp holder body.
4. Replace the threaded plastic shade ring (retaining nut) onto the lamp holder body
5. Install the recommended bulb. (E14 40W MAX GLS Recommended 5.5W LED).
WARNING: TAKE CARE NOT TO OVERTIGHTEN THE BULB. THIS SHOULD BE FULLY INSERTED BUT DOES NOT NEED TO BE FORCEFULLY TIGHTEND. LED BULBS CAN BE EASILY DAMAGED WHICH COULD RESULT IN COLLAPSING OF THE LAMP CAP AND SHORT CIRCUIT.
6. Insert the supply cord plug into a suitable mains outlet and use the in-line cord switch to operate.

Lampshade & Bulb Fitment:

