




## GARMENT RACK SINGLE



### INSTRUCTION MANUAL

Maximum weight per rail: 10kg

Maximum weight per extending rail: 2kg

AFTER SALES SUPPORT

  0800 422 274

# Important Safety Instructions

## Care instructions:

Wipe clean with a damp cloth.  
Do not use abrasive materials or solvents.  
For indoor use only.  
Store in a dry place.

## WARNING:

Do not stand on the garment rack.  
Do not use this product as a step ladder.  
Tighten all screws before using.  
Only use on an even surface.  
Failure to follow these warnings could result in serious injury or damaging the product.

For domestic use only.

# Assembly Details

**10** Min

*Approximate Assembly Time*



*1 Person Assembly*

*Floor Area*  
*1.5 x 0.5 meters*



*Required Assembly Space*

## Tips Before You Start

- 1 Please check that all parts are present before you start the assembly of your furniture.
- 2 For ease and speed of assembly, we recommend that before you commence each step of the assembly, that you identify all the parts required for that step.
- 3 For larger items, please ensure that you have sufficient space and people (as indicated on page 1) to assemble your product safely.
- 4 We recommend that, where possible, all items are assembled near to the area in which they will be placed in use, to avoid moving the product unnecessarily once assembled.
- 5 For the protection of your furniture, we recommend that the product is placed on a protected surface during assembly to prevent any damage.
- 6 During assembly please take care not to over-tighten anything, as this may damage the product. Do not use power tools.
- 7 Always place the product on a steady and stable surface.
- 8 Do not stand on the product. Do not use the product as a stepladder.
- 9 This product is intended for indoor, household use only as it is a non-industrial product.
- 10 Please use caution and care when lifting the product to avoid personal injury and/or product damage.


## Care and maintenance

- ✓ Please periodically check all things and re-tighten as necessary.
- ✓ To clean your item, please use a damp cloth and wipe clean.
- ✓ Never allow any kind of liquid to remain on your furniture. Absorption can cause wood to warp or finishes to de-laminate.
- ✓ Please do not drag and pull your furniture.


# Assembly

#	Pcs	Pieces
A	2	
B	2	
C	4	
D	4	
E	2	
F	4	
G	2	
H	4	
I	4	
J	2	
K	4	


**STEP 1**




**STEP 2**



**STEP 3**




**STEP 4**




**STEP 5**




**STEP 6**



**STEP 7**



**STEP 8**





# living & co.

## Warranty

We pride ourselves on producing a range of quality products that are both packed with features and completely reliable. We are so confident in our products, we back them up with a one-year warranty.

Now you too can relax knowing that you are covered.

Customer Helpline NZ: 0800 422 274

This product is covered by 1 year warranty when accompanied by proof of purchase.

---

**AFTER SALES SUPPORT**

  0800 422 274