

living & co.

Foot Spa




INSTRUCTION MANUAL

FM-516

AFTER SALES SUPPORT

  **0800 422 274**

- A : Drain Spout
B : Splash Guard
C : Control Dial



Important Safeguards

When using electrical appliances, in order to reduce the risk of fire, electric shock, and/or injury to persons, basic safety precautions should always be followed, including:

Safety Instructions

Read all instructions carefully, even if you are quite familiar with the appliance.

- This appliance is not intended for use by children or infirm persons without supervision. Never leave an appliance unattended when in use.
- Young children should be supervised to ensure they do not play with the appliance.
- Switch off and remove the plug from the power outlet before cleaning or when not in use. To unplug, grasp the plug and remove from power outlet. Never pull cord. Never carry the appliance by the cord.
- Do not operate any appliance with a damaged cord or after the appliance malfunctions, or is dropped or damaged in any manner.
- Do not use an appliance for anything other than its intended use. The product is intended for household use only.
- Do not attempt to repair or disassemble the appliance. There are no user serviceable parts.

Safety Instructions (continued)

- Do not use outdoors.
- Do not reach for an appliance that has fallen into water. Unplug it immediately.
- Do not use while bathing or showering.
- Do not place or store the appliance where it can fall or be pulled into a tub or sink.
- Do not place in or drop into water or other liquids.
- Do not attempt to plug or unplug unit while feet are in water.
- Do not use attachments not recommended by the supplier, specifically any attachments not provided with the unit.
- Do not leave the Foot Spa unattended while it is operating.

WARNING

- Never immerse the Foot Spa in water or other liquids.
- Always check the temperature of the water before placing your feet into the Foot Spa.
- Do not stand in the unit. Sit down and place your feet in the Foot Spa.
- Always unplug the unit when not in use and when filling, emptying, cleaning or moving the unit.
- The Foot Spa cannot be used to warm cold water. You must fill the unit with warm water properly as you need.
- Ensure that your hands are dry when operating the switch or removing the plug.

CAUTION

- An appliance should never be unattended when plugged in. Unplug from outlet when not in use.
- Never fall asleep while using the Foot Spa.
- Never drop or insert any object into any opening.
- Do not operate where aerosol (spray) products are being used or where oxygen is being administered.
- If any liquid leaks out, please stop using the product.

Safety Instructions (continued)

CAUTION

- If you have any concerns regarding your health, consult your doctor before using the Foot Spa.
 - Individuals with pacemakers should consult a physician before using the product.
 - In case of pregnancy, diabetes or illness consult your doctor before using the Foot Spa.
 - If you experience pain in a muscle or joint for a prolonged period of time, discontinue use and consult your doctor. Persistent pain could be a symptom of a more serious condition.
 - Never use the Foot Spa on open wounds, discoloured areas, or any area of the body that is swollen, burned, inflamed or where skin eruption or sores are present.
 - Massage and heat should be pleasant and comfortable. Should pain or discomfort result, discontinue use and consult your physician.
- If the supply cord is damaged, it must be replaced by the manufacturer or its service agent or similarly qualified person in order to avoid a hazard.
- This product has not been designed for any uses other than those specified in this booklet.

Foot Spa FM-516

Congratulations on the purchase of your new Foot Spa FM-516.

Before using your new appliance, it is important that you read and follow the instructions in this Use and Care booklet, even if you feel that you are quite familiar with this type of appliance.

Find a place and keep this booklet handy for future reference. Attention is particularly drawn to the section dealing with "Important Safeguards".

This appliance has been designed to operate from a standard domestic power outlet. It is not intended for industrial or commercial use.

How to Use Your Foot Spa

- Ensure that the unit is unplugged before filling with water. Fill the Foot Spa up with warm water.
- Connect the supply plug to the mains supply and switch on.
- Sit down and place your feet in the spa.
- Turn the function control dial to indicate the massage of your choice and obtain the following functions:
 - 0--Off
 - 1--Vibration
 - 2--LED Light
 - 3--Vibration & LED Light
- Enjoy the deep-penetrating massage while moving your feet forward and backward over the reflex zone.
- The plastic nodes are designed to stimulate pressure-points on your feet and reduce fatigue.

To Empty

- First, turn all controls to the 'OFF' position, then unplug the unit. Tip the unit allowing water to spill out along the drain spout. Never pour water over the control switch.

Maintenance

To Clean

Unplug the unit and allow it to cool before cleaning. Clean only with a soft, damp cloth.

- Never allow water or any other liquid to come into contact with the control switch.
- After cleaning, wipe surfaces with a dry cloth.
- Never use abrasives, detergents or cleaning agents.
- Periodically straighten the cord if it becomes twisted.

To Store

Unplug the appliance from the outlet and allow cooling, ensure drained and dry.

- Store in its box or a clean, dry place.
- To avoid breakage, do not wrap the power cord around the unit.

WARRANTY

The original purchaser of this foot spa is provided with the following warranty, subject to the following conditions.

We warrant this product for a period of 1 year from the date of purchase for all parts defective in workmanship or materials. The product or defective parts will be replaced free of charge.

WARRANTY CONDITIONS

1. This warranty is only valid for appliances used according to the manufacturer's instructions.
2. This appliance must not be modified or changed in any way.
3. Connection must be to the voltage requirements as specified in the rating label located on the product.
4. The manufacturer does not accept liability for any direct or consequential damage, loss or other expense arising from misuse or incorrect installation and operation of the appliance.
5. Warranty will only be given where proof of purchase is provided, e.g. original invoice.
6. Not designed or warranted for industrial or commercial use.

RETAIN & FILE WITH YOUR RECEIPT.

Your Purchase Receipt/ Invoice is proof of date of purchase. You must be able to present it at the place of purchase to obtain a replacement or service under warranty.

We reserve the right to discontinue items, modify designs and change specifications without incurring obligation.

Whilst every effort is made to ensure that descriptions, specifications and other information in this publication is correct, no warranty is given in respect thereof and the company shall not be liable for any errors therein.

TECHNICAL SPECIFICATIONS: 230V~ 50Hz, 5W, Class II



living & co.

Warranty

We pride ourselves on producing a range of quality home appliances that are both packed with features and completely reliable. We are so confident in our products, we back them up with a 1 year warranty.

Now you too can relax knowing that you are covered.

Customer Helpline NZ: 0800 422 274

This Product is covered by a 1 year warranty when accompanied by proof of purchase.

IM Version 1.0 - MAY 2018

