

poppi

LED Light Skincare Wand

USER MANUAL
Model: BA10557

Before operating this product, please read these instructions completely and save this manual for future use.

AFTER SALES SUPPORT
☎ 0800 422 274

Features

Type-C Charge

Button Switch

Massage head can rotate 330°

What's Included

1 LED Light Skincare Wand
1 USB Type C Charging Cable
1 User Manual

The skincare wand features 7 LED colour modes to assist a wide range of common skin concerns — including visible signs of aging, uneven tone, and the appearance of blemishes or redness. Each LED mode uses specific light wavelengths that work at different depths of the skin's surface to help promote a more radiant, balanced, and refreshed look.

LED Light Technology – What does it do?
LED light technology offers a gentle, non-invasive way to support the look and feel of your skin. By using carefully selected light wavelengths, this helps improve the appearance of dullness, fine lines, visible pores, and skin clarity. With 7 light modes, it offers a customizable experience to help you achieve your skincare goals.

Functions:

ON: Press and hold the 'Button Switch' for 2 seconds.
OFF: When on, press and hold the 'Button Switch' for 2 seconds.
LED light modes: When On, subsequent presses of the 'Button Switch' will step through 7 different colour options as follows:

Red Light May help enhance the appearance of firmness and promote a youthful-looking glow. Red light supports the look of smoother, revitalised skin

Blue Light May help refresh and balance the look of skin, especially in areas prone to excess oil. Use to support a visibly clearer, refined complexion.

Green Light May help calm the appearance of skin and promote a more even-looking tone. Perfect for adding a soothing step to your skincare routine.

Purple Light May help visibly calm the appearance of stressed or uneven skin, supporting a clearer, more balanced-looking complexion.

Cyan Light May help soothe and balance the appearance of the skin, often used after Blue or Red light application.

Yellow Light May help visibly improve skin clarity and tone, promoting a brighter and more even-looking complexion.

White Light May help enhance overall skin appearance by supporting a balanced, refreshed, and revitalized look by combining multiple light wavelengths.

AFTER SALES SUPPORT
☎ 0800 422 274 **poppi 1**

Usage Method

Operation

01
Apply recommended amount of eye cream or essence (product to hydrate skin) around the eyes to keep the skin moist.

02
Gently slide the massage head, lift and massage the skin around the eyes, repeat 15-20 times;

03
Gently press the massage head to improve the absorption of eye cream or essence (product to hydrate skin). Stay at each point for about 10 seconds and repeat for 2-3 times.

04
You can also massage the cheeks, chin and other parts according to the above operation methods. You can use the lifting method to help improve the appearance of fine lines.

Tip: It is more convenient to rotate the massage head to the right.

05
After use, wipe the massage head with a clean cloth, wet towel (or alcohol cotton)

06
In addition to massaging the eye contour, you can also massage the whole face and other parts of the body (such as the waist and legs)

poppi 2 AFTER SALES SUPPORT
☎ 0800 422 274

Charging

1. Insert the USB plug into the a 5V DC USB-A outlet (power supply or laptop output etc) and connect the Type-C USB plug into the charging socket at the bottom of the product.
2. When the indicator light flashes, it is in the charging state;
3. When the indicator light remains on, the battery is fully charged and the charge cable should be disconnected.
4. When in use, if the indicator light flashes frequently, this indicates battery power is reducing, it should be charged immediately, otherwise it will stop working.
5. Take care of the charging cable, keep with the device and never expose to water.

Warning ⚠

-This product is not waterproof. Do not place the equipment near the bathtub sink or washbasin to prevent it from falling in and damaging the equipment.

-Please ensure that the battery is fully charged at least once within 3 months, otherwise permanent damage may occur.

-When using, the massage head can be rotated left and right, and the maximum rotation range is 330°, never apply force to extend beyond.

-Keep out of reach from children! Please ensure children do not play with the product.

-DO NOT purposely stare at the LED lights for extended periods.

AFTER SALES SUPPORT
☎ 0800 422 274 **poppi 3**

Tips for eye protection

⚠ attention

- Please fully charge the battery when using it for the first time (approximately 2 hours).
- Before use, please clean your skin, remove cosmetics and dirt and remove watches, earrings, glasses, contact lenses and other metal accessories.
- Do not use if you are pregnant, or have recently received plastic surgery.
- Apply moisturiser / essence on the skin area intended to be massaged in order to keep skin moist.
- Don't stay in the same place for a long period in order to avoid scalding. If the skin is damaged, please discontinue use.
- After use, you can do a daily skin care and moisturising facial mask.

NOTE: The wand is not waterproof, but you can use a damp cloth to clean the residue on the wand, then dry fully with a paper towel.

AFTER SALES SUPPORT
☎ 0800 422 274 **poppi 4**

Product Parameters

Product name LED Light Skincare Wand	Battery capacity 350mAh	Dimensions 6" x 0.63" x 0.43
Light Modes	Charging input 5V DC /1A	Product weight 35g
Main materials Metal & PC plastic	Charging time About 2 hours	Power 1.5W
LED quantity 12	Wavelengths 456-630nm:1	Box dimensions 6.87" x3.25"x1.1"

Product Overview

AFTER SALES SUPPORT
☎ 0800 422 274 **poppi 5**

FAQ

Q: Why can't the machine be started sometimes?
Answer: Maybe the power is insufficient, it is recommended to use after fully charging.

Q: How often are they used?
Answer: It is recommended to use it for 5-10 minutes each time, 3-5 times a week.

Q: Why can't I use it when charging?
Answer: For safety, we can't use it during the charging process. Can only be used after fully charging.

Q: Is the product waterproof?
Answer: No, but it can be gently cleaned with a very damp soft cloth or similar, dry with paper towels after use.

Q: How long does it take to recharge?
Answer: It takes about 2 hours to charge, and you can use it 4-5 times for each full charge.

Q: How should I dispose of the product at the end of its working life?
Answer: The wand includes a lithium battery. Please contact your local council for details on where electronic-waste products can be disposed of safely for environmental protection purposes.

AFTER SALES SUPPORT
☎ 0800 422 274 **poppi 5**

Read the manual, it will help you get the best out of your product.

STOP
Turn off the power

Still have questions?
Call After Sales Support
0800 422 274

poppi

Warranty

We pride ourselves on producing a range of quality home appliances that are both packed with features, and completely reliable. We are so confident in our products, we back them up with a one year warranty when accompanied by proof of purchase.

Now you too can relax knowing that you are covered.
Customer Helpline NZ: 0800 422 274
IM Version 1.0 – April, 2025

AFTER SALES SUPPORT
☎ 0800 422 274 **poppi 6**

70mm

130mm