


# LIVING&CO

## ROUND FIRE PIT Model No. LF250



### **WARNING!**

PLEASE READ THESE INSTRUCTIONS CAREFULLY BEFORE ASSEMBLY AND USE. FAILURE TO FOLLOW THESE INSTRUCTIONS COULD RESULT IN DEATH, SERIOUS BODILY INJURY AND/OR PROPERTY LOSS. READ AND FOLLOW ALL INSTRUCTIONS CAREFULLY BEFORE ASSEMBLY OR USE OF THIS BURNER.

**Retain these instructions for future use.**

---

**Important:** The installer or seller must leave these instructions with the consumer.

---



## WARNING

Failure to read and follow this manual and the safety warnings herein may result in serious bodily injury or death, or in a fire or an explosion causing damage to property.

### Important

Check with your local council regarding fire bans before using your Fire Pit.  
Check with your local council regarding Air Quality Regulations which may affect use.

-  **IMPORTANT** Only use this Fire Pit on a flat, level non-flammable surface or ground.
-  This product is for **OUTDOOR USE ONLY**. NEVER use in an enclosed space such as a carport, garage, veranda, covered patio, or under an overhead structure or vegetation of any kind.
-  **ATTENTION!** This Fire Pit will become very hot. Do not attempt to move it during operation.
-  **WARNING!** Keep children and pets away from the Fire Pit when in use. Any modification of this Fire Pit may be dangerous.
-  When positioning, ensure the Fire Pit is a minimum of 1 metre from flammable items or structures.
-  Do not overfill metal tray with fuel.
-  Never handle hot parts with unprotected hands.
-  **DO NOT USE INDOORS!** If used indoors, toxic fumes can build up and cause bodily injury or death. Only use outdoors in a well-ventilated area.
-  **ATTENTION!** This Fire Pit should not be used under overhead combustible construction.
-  NEVER leave this Fire Pit unattended when in use.
-  Do not add starter fluid or charcoal impregnated with starter fluid to warm or hot fires.
-  Do not use clothing with long or loose sleeves when operating the Fire Pit.
-  Do not use the Fire Pit in high winds. Do not touch the Fire Pit with your hands to check if it is hot.
-  Do not use water to control flare-ups or extinguish fuel. Always extinguish your Fire Pit when not being monitored
-  Do not dump hot charcoal or embers where they may cause a fire hazard. Do not store away or cover the Fire Pit until all embers are extinguished and removed, and the Fire Pit is fully cooled.
-  This Fire Pit is not intended to be used in recreational vehicles or boats.
-  **CAUTION!** Do not use petrol, spirit or lighter fluid for lighting or re-lighting the Fire Pit!
-  Do not hang any combustible materials from this Fire Pit.
-  Protective gloves or mitts should always be used while cooking, lighting or adjusting and handling the Fire Pit.


# LIVING&CO

## PARTS LIST

Please check parts against the list below before assembling the Fire Pit. Take a few moments to familiarise yourself with the contents. Check that all holes are clear of paint before assembly.

1	Cover		1
2	Handle		1
3	Tray		1
4	Leg		3
5	Hook		3

6	Grate		1
7	Tool		1
A	M8 nut		6
B	M8 ring		6
C	M6 lock nut		1



WARNING



- Dispose of all polythene packing carefully and keep out of the reach of children.
- Please read the section on burner safety prior to using your burner.

Please read all instructions carefully and keep outer packaging to refer to photograph of finished product in case of difficulty.

# LIVING&CO

## ASSEMBLY



### WARNING

- While every effort has been made in the manufacture of your burner to remove any sharp edge, you should handle all components with care to avoid accidental injury.



- Tools required: Either a Philips crosshead or flat-bladed screwdriver and either an adjustable wrench or a pair of pliers.

1. Attach leg (4) to tray (3) using two nuts (A) and two rings (B) per leg.
2. Attach hooks (5) to tray (3) in order to hold the cover (1).
3. Insert handle (2) into cover (1) using lock nut (C) and make sure it is security.
4. Insert grate (6) into the tray (3). The position of this can be adjusted using hand tool (7).

Now your burner is ready for use.

