

Living & Co

PARTY TIME 36CM GLITTER LAMP

Instructions

Please read these instructions and warnings carefully before operating to ensure safe and satisfactory operation of this product.

Please also retain these instructions for future use.

Warnings:

- This is a Class II product and does not require an earth connection.
- Always use the correct type and wattage of bulb.
- When changing a bulb, always switch off the light at the wall socket and allow the bulb to cool down before handling.
- Dispose of old bulbs carefully.
- Do not switch on the light until the assembly is complete.
- Do not cover the lamp or bulb during use as this could be a potential safety hazard
- Turn off the appliance when not in use.
- The luminaire is not intended for use by children unless suitable adult supervision is provided.
- Children should be supervised to ensure they do not play with the luminaire.
- The fitting is intended for indoor use only.
- If the external flexible cable or cord of this luminaire is damaged, it shall be exclusively replaced by the manufacturer or his service agent or a similar qualified person in order to avoid a hazard.
- Take extra care when placing the glass glitter bottle onto the base to avoid breaking.
- When re-locating the lamp fitting, support the glass glitter bottle with one hand and the base with the other, carefully hold together to avoid the glass glitter bottle displacing.
- Never attempt to open the glass glitter bottle. Do Not Drink Contents. If leaking occurs, the assembly must be disposed of.
- Do not place lamp in direct sunlight. The colours may fade.
- Do not move, shake or drop your lamp while "WARM."

CAUTION: Ensure that the light bulb is not within the recommended 0.5m of any surface when operating as this could be a potential safety hazard.

CAUTION: Never exceed the bulb wattage stated.



This lamp fitting attains a high operating temperature, Do Not Touch the glass when in operation or until the surface has cooled.

Assembly:

1. Remove any protective packaging from the lamp fitting and glass glitter bottle.
2. Place the lamp fitting base on a stable / dry and level support surface.
3. Check the bulb is fitted in position (loosening may have occurred in transit). Reach into the base and gently rotate the bulb clockwise to ensure fitted correctly in position.
4. Place the glass glitter bottle carefully onto the lamp fitting base.
5. Place the decorative cap on the top of the glass glitter bottle
6. Insert the supply cord plug into a suitable mains outlet and use the in-line cord switch to operate.

NOTE 1: If the lamp fitting does not illuminate, please check that the mains socket outlet is working and that the cord-line switch is in the on position. If the light still does not operate, it is likely that the bulb is blown or damaged and will need replacement. To remove the bulb, REMOVE THE SUPPLY PLUG from the mains supply socket then carefully lift away the glass glitter bottle from the base. Rotate the bulb anti-clockwise to remove.

NOTE 2: Please be patient. The first time you start your Lamp, it will take some time to reach operating temperature (approximately 2 – 4 hours).

NOTE 3: We recommend only running your lamp for 8-10 hours at a time.

