

Instructions

Please read these instructions and warnings carefully before operating to ensure safe and satisfactory operation of this product.

Please also retain these instructions for future use.

Warnings:

• This is a Class II product and does not require an earth connection.

• Always use the correct type and wattage of bulb.

• When changing a bulb, always switch off the light at the wall socket and allow the bulb to cool down before handling.

- Dispose of old bulbs carefully.
- Only use the lamp fitting on a stable / dry and level support surface.
- Do not switch on the light until the assembly is complete.
- Do not cover the lamp or bulb during use as this could be a potential safety hazard
- Turn off the appliance when not in use.
- The luminaire is not intended for use by children unless suitable adult supervision is provided.
- Children should be supervised to ensure they do not play with the luminaire.
- The fitting is intended for indoor use only.

• If the external flexible cable or cord of this luminaire is damaged, it shall be exclusively replaced by the manufacturer or his service agent or a similar qualified person in order to avoid a hazard.

CAUTION: Ensure that the light bulb is not within the recommended 0.5m of any surface when operating as this could be a potential safety hazard. **CAUTION:** Never exceed the bulb wattage stated.

Assembly and operation:

- 1. Remove any protective packaging from the light fitting.
- 2. Install the recommended bulb.
- 3. Place the lamp fitting on a stable / dry and level support surface.
- 4. Insert the supply cord plug into a suitable mains outlet and use the integrated on/off rocker switch on the body of the fitting to operate.
- 5. The articulated lamp head can be manually adjusted by bending the flexible stem to the desired position. WARNING: Do not use excessive force when adjusting.

Light bulb fitment:

