



TOUCH LAMP

Instructions

Please read these instructions and warnings carefully before operating to ensure safe and satisfactory operation of this product.

Please also retain these instructions for future use.

Warnings:

- This is a Class II product and does not require an earth connection.
- Always use the correct type and wattage of bulb.
- When changing a bulb, always switch off the light at the wall socket and allow the bulb to cool down before handling.
- Dispose of old bulbs carefully.
- Only use the lamp fitting on a stable / dry and level support surface.
- Do not switch on the light until the assembly is complete.
- Do not cover the lamp or bulb during use as this could be a potential safety hazard
- Turn off the appliance when not in use.
- The luminaire is not intended for use by children unless suitable adult supervision is provided.
- Children should be supervised to ensure they do not play with the luminaire.
- The fitting is intended for indoor use only.
- If the external flexible cable or cord of this luminaire is damaged, it shall be exclusively replaced by the manufacturer or his service agent or a similar qualified person in order to avoid a hazard.
- To prevent damage to the mains cord, do not let it pass over sharp corners, edges or hot surfaces.
- This lamp should only be used on a flat and stable surface.
- This lamp is not intended for use by persons with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance, by a person responsible for their safety.
- Never touch the bare bulb with your bare fingers or hands.
- Grease or oil from fingers can damage the bulb and cause the bulb to burn out, or reduce its operating life, it is recommended to use soft cloth or facial tissue when handling the bulb.
- This lamp incorporates a (touch) dimmer switch control. When using LED type bulbs, please check that the bulb type is compatible and can be used with dimmer applications.

CAUTION: Ensure that the light bulb is not within the recommended 0.5m of any surface when operating as this could be a potential safety hazard.

CAUTION: Never exceed the bulb wattage stated.

Assembly and operation:

- Remove protective plastic overwrap from the lamp shade and ensure any packaging materials are removed from the light fitting.
1. Remove the threaded plastic shade ring (retaining nut) from the lamp holder and install the lamp shade onto the lamp holder body.
 2. Replace the threaded plastic shade ring (retaining nut) onto the lamp holder body by rotating clockwise until secure.
 3. Insert the recommended light bulb.
 4. Place the lamp fitting on a stable / dry and level support surface.
 5. Insert the supply cord plug into a suitable mains outlet. The lamp fitting incorporates a 'touch switch' facility, simply touch the base with your hand once to switch on - low brightness, touch again for medium brightness, touch again for full brightness, touch once more to switch off.

