

Responsible Disposal

At the end of its working life, Observe any local regulations regarding the disposal of electrical consumer goods and dispose of it appropriately for recycling. Contact your local council for advice on recycling facilities in your area. In the event it is to be disposed of, please recycle all packaging material where possible.



living & co.

Warranty

We pride ourselves on producing a range of quality products that are both packed with features and completely reliable. We are so confident in our products, we back them up with a 1 year warranty.

Custom helpline NZ: 0800 422 274

This Product is covered by a 1 year warranty when accompanied by proof of purchase.

living & co.

living & co.

LENNON USB LED LANTERN



Instruction Manual
Model No. LS7R01

living & co.

6 Warnings

1. The lamp contains a rechargeable lithium battery. Do not expose the battery to heat sources or sustained periods of direct sunlight.
2. The light source in this product is a non-replaceable LED bulb.
3. The product must only be repaired by a suitably qualified service technician.
4. Please do not over-adjust the joint parts of the lamp to avoid any damage.
5. Please do not use the lamp in the high-temperature or high-humidity environment.
6. This product is NOT a toy. Keep out of reach of small children. Young children should be supervised to ensure that they do not play with this product.
7. Do not immerse in water or any other liquid.
8. Charge the battery with a DC5V Output via a USB power supply (not included).
9. Disconnect the USB cable from the product when it is fully charged or no longer in use.
10. Disconnect from the USB power supply and cease to use the product immediately if it begins to show visible smoke or give off unusual smells during the charging process.
11. Do not handle the product with wet hands whilst it is being charged or connected to a power source.
12. Do not immerse the USB cable or charger (Not Supplied) in water or any other liquid.
13. Only leave connected to the charging source for the recommended duration, charging should be performed with the product attended only.
14. If the product is not being used regularly, it must be charged at least every 3 months to avoid permanent damage to the battery.

living & co.

3 Technical Parameters

Control Type	Touch
Input	DC5V 1A
Cable Length	100cm
Rechargeable Battery	1200mAh
Charge Time	4 Hours
Run Time	3-5 Hours (Full Charge)
Material	Metal+Plastic

living & co.


Contents

- 03 Technical Parameters
- 04 Operation
- 05 Operation Instructions
- 06 Warnings

living & co.

4 Operation

Touch to turn on light



living & co.

5 Operation Instructions

1. The lamp is turned on and off by touching its top side (touch switch).
2. To change the light intensity, touch and hold the top button and the light brightness will vary.
3. To change the light colour, a quick touch of the top button and the light colour will switch from yellow to natural white, then to warm white. Subsequent presses will cycle through the options.

Charging

1. Insert the USB-C (smaller connector) into the charging socket, ensuring fully inserted.
2. Connect the USB connector to a suitable 5V DC USB socket outlet and switch on.
3. Leave to charge for the recommended time (Approx. 4 hours), then disconnect the cable.
WARNING do not leave to charge for longer than the recommended time.

living & co.