



ACTIVE INTENT
PLAY

TRAMPOLINE

OWNER'S MANUAL



Trampoline should be assembled on the flat lawn.

ATTENTION! This trampoline is supplied with a safety net and must be installed. This safety net is designed to significantly reduce the trampoline user from falling off.

This net is NOT designed for rebounding, climbing or hanging off.

Failure to install the safety net or misuse of the net will increase the risk of injury.

The safety net does not replace the need for supervision and to ensure that users of this trampoline are informed of all warnings and safety instructions.

IMPORTANT: Read all instructions carefully before using this product. Retain this owner's manual for future reference. The specification of this product may vary from this photo, subject to change without notice.

Table of Contents

SAFETY INSTRUCTIONS	2
CARE AND MAINTENANCE	3
TRAMPOLINE PARTS LIST	4
EXPLODED DIAGRAM	5
ASSEMBLY INSTRUCTIONS	6
ENCLOSURE PARTS LIST	8
SAFETY ENCLOSURE ASSEMBLY	9

When ordering replacement parts please have the following information ready:

1. Owner's Manual
2. Model Number
3. Description of Parts
4. Part Number
5. Date of Purchase

Customer service number: 0800 422 274

MON - FRI: 8AM - 5PM

SAT - SUN: 9AM - 4PM


Marketed By: The Warehouse LTD
26 The Warehouse Way, Northcote, Auckland

Warning								
ITEM	6FT 3W	8FT 3W	10FT 3W	12FT 4W	13FT 6/4W	14FT 6/4W	15FT 6/5W	15FT 6W
Max Weight Limited:	75KG	100KG	120KG	150KG	150KG	150KG	150KG	150KG

Safety Instructions

Read and understand all this information provided to you in this manual before you begin using your trampoline. As with all physical sports and activities there is the risk of participants receiving an injury. To ensure your future enjoyment and the prevention of injury, be sure to follow appropriate safety rules and tips.

- ▲ Always consult a doctor/physician before performing any kind of physical activity.
- ▲ Always check your trampoline before use, paying specific attention to all the bolts, jump mat and pads position. Don't use if any parts are missing or look like they show wear, tear or break.
- ▲ Always ensure that the trampoline is used by only one person at all times.
- ▲ Always ensure that whenever the trampoline is used by anyone at any skill level that they do so under supervision.
- ▲ Stop exercising immediately should you feel unwell or if you feel pain in your joints and muscles. Dizziness is a sign of fatigue and you should stop bouncing and lay down on the ground should you feel dizzy.
- ▲ When using this trampoline, ensure appropriate clothing is worn, preferably sports wear and socks. Never wear shoes on the mat.
- ▲ Please be warned that the trampoline is spring based and will allow the user to jump to a greater height than that on the ground, so please bear this in mind and ensure that you are comfortable bouncing at low heights first.
- ▲ Proper assembly, care and maintenance of the product, safety tips, warnings, and proper techniques for jumping on your trampoline are included in this manual for your safety and an extended product lifespan. All users and supervisors should therefore familiarize themselves with these instructions. Anybody who chooses to use the trampoline must be aware of their own limitations with regards to performing skills on this trampoline.
- ▲ Trampoline should be assembled on grass or BSI approved safety matting.
- ▲ DO NOT perform somersaults of any type (backwards or forwards) on this trampoline. If you make a mistake when trying to perform a somersault, you could land on your head or neck. This will increase your chances of your neck or back being broken, which could result in death or paralysis.



- ▲ DO NOT use the trampoline if there are pets, other people, or any objects underneath the trampoline. This will increase the chances of an injury occurring, DO NOT hold any foreign objects in your hand and DO NOT place any objects on the trampoline while in use. DO NOT place the trampoline under over-hanging objects like tree branches, wires, etc., as these will increase your chances of being injured.
- ▲ A trampoline in poor condition will increase your risk of being injured. Please inspect the trampoline before each use for bent steel tubes.
- ▲ Please be aware of the of the weather conditions when using the trampoline. If the mat of the trampoline is wet, the user could slip and injure himself/herself. If it is too windy, the user could lose control.
- ▲ When the trampoline is not in use, always store securely so that unsupervised children cannot play on the trampoline.

CARE AND MAINTENANCE

This trampoline is designed to withhold a certain amount of weight and use. Please make sure that only one person at any one time uses the trampoline. Also, the person should weigh less than max weight limited. Jumpers should either wear socks, gymnastics shoes, or be barefoot when using the trampoline. Please be aware that street shoes or tennis shoes should NOT be worn while using the trampoline. In order to prevent the trampoline mat from getting cut or damaged please do not allow any pets onto the mat. Also, jumpers should remove all sharp objects from their person prior to using the trampoline. Any type of sharp or pointed objects should be kept off the trampoline mat at all times. Foreign objects including wakeboards, snowboards, skateboards, bicycle or any other items are not to be used with the trampoline. Do not hang from, kick, cut through or climb on the enclosure net.

The product must not be used until properly and fully installed and checked. Always inspect the trampoline before each use for worn, abused or missing parts. A number of conditions could arise that may increase your chances of getting injured. Please be aware of:

- Punctures, holes, or tears in the trampoline mat
- Sagging trampoline mat
- Loose stitching or any kind of deterioration of the mat
- Bent or broken frame parts, such as the legs
- Broken, missing, or damaged springs
- Damaged, missing, or insecurely attached frame pad
- Protrusions of any types (especially sharp types) on the frame, springs, or mat

IF YOU FIND ANY OF THE PREVIOUS CONDITIONS, OR ANYTHING ELSE THAT YOU FEEL COULD CAUSE HARM TO ANY USER, THE TRAMPOLINE SHOULD BE DISASSEMBLED OR SECURED FROM USE UNTIL THE CONDITION(S) HAS BEEN RESOLVED. DO NOT ATTACH ANYTHING TO THE PRODUCT THAT IS NOT A MANUFACTURER-APPROVED ACCESSORY.

WINDY CONDITIONS

In severe wind situations, the trampoline can be blown about. If you expect windy weather conditions, the trampoline should be moved to a sheltered area or disassembled. Another option is to tie the round, outside portion(top frame)of the trampoline to the ground using ropes and stakes. To ensure security, at least three (3) tie downs should be used. Do not just secure the legs of the trampoline to the ground because they can pull out the frame sockets.

MOVING THE TRAMPOLINE

If you need to move the trampoline, two people should be used. All connector points should be wrapped secured with weather resistant tape, such as duct tape. This will keep the frame intact during the move and prevent the connector points from dislocating and separating. When moving, lift the trampoline slightly off the ground and keep it horizontal to the ground. For any type of other move, you should disassemble the trampoline.

Trampoline should be assembled on the flat lawn.

ATTENTION! This trampoline is supplied with a safety net and must be installed.

This safety net is designed to significantly reduce the trampoline user from falling off.


This net is NOT designed for rebounding, climbing or hanging off.

Failure to install the safety net or misuse of the net will increase the risk of injury.


The safety net does not replace the need for supervision and to ensure that users of this trampoline are informed of all warnings and safety instructions.

TRAMPOLINE PART LIST

PARTS	ITEM
Frame Cover	A
Jumping Mat	B
Top Rail	C
Springs	E
Leg Extension	F
W-Shaped Leg	G
Screw	H
Tool(Optional)	I



A Frame Cover




B Jumping Mat



C Top Rail




E Spring



W-Shaped Leg Piece



H Screw




I Tools

TRAMPOLINE FRAME ASSEMBLY

Refer to Parts List for identification of parts.


WARNING: 2 adults in good physical condition are required for the following assembly. Wear proper shoes and maintain balance to prevent a fall. Failure to follow all instructions and warnings exactly may result in serious injury.



1. Lay out all trampoline parts in groups (just like picture)



2. Begin by attaching two leg extensions to assemble one "W" shape leg with rail screws (part H).



3. Attach the top rail as picture.



4. Continue until you form a large circle. Joining the last link may require two or more adults in good physical condition. With a second person holding the opposite end, bring both sides of the circle firmly together and make them secured.



5. Attach the leg assemblies making all secured.



6. Now the frame assembly is complete.



7. With stitching portion facing down, lay jumping mat inside frame and attach a spring into one of the triangle rings on the mat. Then attach spring with ring to frame.

WARNING: Trampoline is under heavy tension, more effort may be required to attach springs to frame. Be careful not to pinch fingers or slip. Serious injury may occur!

TRAMPOLINE MAT & COVER ASSEMBLY

DANGER: 2 adults may be required to complete placement of all springs as illustrated in STEP 13. Springs will create high levels of tension when assembled. Please use extreme caution not to pinch your fingers.



8. Repeat this step directly across from where you attached first spring. Then attach two more springs half distance between the first two, directly across from each other.



9. Use spring tool as shown.



10. Springs under heavy tension may require adjacent springs to be attached every four or five holes, making the springs tension averagedly distributed.



11. Attach remaining springs until all springs are placed on frame securely.



12. Lay blue frame cover on outer edge so springs are covered-just like a shower cap.
Caution: please always keep the side with "this side up" up.



13. Tie all black straps to top rail of frame. Do not tie to springs.









14. Your trampoline is now ready for the enclosure to be attached!

To disassemble repeat steps 1-14 in reverse.

ENCLOSURE PARTS LIST


PARTS	10' 3 Legs	12' 4 Legs	ITEM NO.
Upper eye bolt set	6	8	A
Lower flat-head bolt set	6	8	B
Plastic cap on screw	12	16	C
Pole cap	6	8	D
Pole bottom	6	8	E
Wrench	1	1	F
Upper pole	6	8	G
Lower pole	6	8	H
Safety enclosure net	1	1	I



I Safety enclosure net(1)

SAFETY ENCLOSURE ASSEMBLY


WARNING: 2 adults in good physical condition are required for the following assembly. Wear proper shoes and maintain balance to prevent a fall. Failure to follow all instructions and warnings exactly may result in serious injury.



1. Slide upper pole onto lower pole.
Repeat with remaining poles.



2. Place the safety enclosure net on trampoline tidily as shown ready for next step.



3. Note: Firmly fix the lower pole and the leg extension with Upper eye bolt set(A) and Lower flat-head bolt set.(B) Then fasten the bolt by wrenching on the nut.
After succeeding in the first pole, repeat to all poles.



4. After firmly clamping all the poles to the trampoline legs, put the cup hat on each of the upper poles tightly.
5. Fasten the net with the cup hat.



6. Repeat with remaining, until all the cup hats are fastened to the net.



7. Make the rope go through the under part of net and the V-rings slightly.



8. Ending at the entrance slide fastener and hooks. Responsible adult supervisor, must re-zip the slide fastener and re-hook all the hooks securely before jumping begins.



9. Congratulations, your trampolines safety enclosure is now complete!