


Product Introduction



SAFETY INSTRUCTIONS

Never charge unattended. When charging, should always remain under constant observation to monitor the charging process and react to potential problems that may occur. Do not charging a power bank on the bedside cabinet while you sleep. Do not charge a power bank under a pillow, on the bed or on a couch – it can overheat and cause a fire.

Do not use or charge a power bank that shows sign of swelling, overheating or damage, if the power bank starting to swell or heat up, discontinue charging process immediately. Disconnect the battery and let it cool down.

Only use the power bank that is designed for the device. Do not use the power bank for anything other than the intended use.

Only use the charging equipment that came with the device, and don't use it if it is damaged.

Do not use the power bank has been dropped or damaged in any way.

Do not expose this power bank to extreme temperatures or excessive heat as it may damage the power bank and it could ignite a fire. Do not leave the power bank in direct sunlight or in hot vehicles.

Do not attempt to disassemble or modify this power bank as it may cause damage or cause a fire.

Do not immerse the power bank in water.


Disposing of lithium ion and Lithium polymer batteries:

Don't put lithium ion batteries in the rubbish.

Recycling is always the best option - AT a battery recycling location or contact your local council for disposal options.


Don't store large piles of discarded batteries.

1. Charging the power bank



- Connect the USB charge cable to a USB power source, and connect the other end of the cable to the micro USB input on the power bank for charging, LED indicator will flash, once the power bank charged in full, the LED indicator will light in solid.

2. Charging your device



- Connect your device to the power bank output port with charging cable specific to your device
- The LED indicator will turn on when it start charging.

Product Specifications

Input	Micro: 5V-2A / 9V-2A USB-C: 5V-3A / 9V2A
Output	USB A / USB-C: 5V-3A / 9V-2A / 12V-1.5A
Capacity	30000mAh
Cell Type	Li-Polymer Battery

Attention

- Do not expose charger to extreme temperatures or moist environments.
- Keep away from liquids; store in dry areas.
- Close supervision should be provided if used by children
- Do not disassemble or apply excessive pressure.
- Do not use charger with any device outside the mentioned output parameters.



WARRANTY CARD

This product is guaranteed against faulty materials and workmanship for a period of two years from the date of purchase with proof of purchase. Under this warranty, the warrantor's obligation to the purchaser is to remedy manufacturing faults by repairing or replacing faulty parts or, if unable to be remedied, replacing or refunding the product with proof of purchase. This warranty becomes void if the product has been tampered with or damaged in any other way by improper use. This product has been quality inspected. In the unlikely event of a deficiency, please contact the retailer from which this product was purchased.

IMPORTANT

Please retain this warranty card along with your purchase receipt. Please do not post to the retailer or importer. If service is required, both of these documents are to be returned with the product to your retailer, otherwise a fee may be charged.

WARRANTY FOR PRODUCTS USED COMMERCIALY LIMITED TO 90 DAYS

Please fill this in upon purchase in case you lose your receipt.

Model Number: _____
 Serial Number: _____
 Date of Purchase: _____
 Receipt Number: _____
 Store Purchased from: _____

Customer support line 0800 422 274
 For assistance during normal working hours
 Monday – Friday, 9am – 5pm, New Zealand local time