



## THE NEXT-GEN BLENDER



Take your cordless, portable blender anywhere to shake up your routine.

Make a smoothie, shake or cocktail in 20 seconds, anywhere.

Get all the juicy details you need to blend like a pro at [BlendJet.com/Guide](https://BlendJet.com/Guide).

## YOUR FIRST BLEND

①

Charge your BlendJet with the included USB cable for 1 hour or until you see a solid blue circle.

②

Ensure the arrows on the back of the jar & base are closely aligned. Power button will flash white.

③

Clean your BlendJet by blending water with a drop of soap, then rinse. (Deep clean as needed – visit [BlendJet.com/Guide](https://BlendJet.com/Guide) for video demo).

④

Add liquid first, then throw in your solids. Leave a little room at the top.

⑤

Tighten the lid & press the power button to blend for one 20-second cycle. Repeat as needed for thicker blends.

⑥

Enjoy your blended creation & clean immediately after each use.

## FLAVOR ON FULL BLAST

### Meet the JetPacks

Make a delicious, nutritious, juice-bar-quality smoothie anytime, anywhere.



No refrigeration needed, just add water—or get creative with your favorite milks, fruits, protein powders, yogurts or superfoods.

JetPacks' fruit is picked at peak ripeness & immediately freeze dried, locking in flavor, color & nutrients like potassium, calcium, iron & fiber.



Gluten Free



Good Source of Fiber



Vegan



No Artificial Flavors or Preservatives



Non-GMO



No Artificial Sugar

Get yours at [BlendJet.com/JetPacks](https://BlendJet.com/JetPacks).



Let us know if you need anything!  
[support@blendjet.com](mailto:support@blendjet.com)

@blendjet



## POWERING UP

BlendJet takes about 1.5 hours to fully charge & lasts for 15+ blends. Battery life is visible while charging.



**Zero Charge**  
Circle flashes red & purple.



**50% Charge**  
Circle is half purple, half blue.



**Full Charge**  
Circle is solid blue.

Circle will turn purple (vs. blue) while blending to indicate low battery.

## TROUBLESHOOTING



**Flashing Red**  
*Jar isn't aligned with base.*

Loosen jar from base & screw it back in until arrows on back of jar & base are closely aligned, and the power button flashes white instead of red.



**Solid Red**  
*Blades are blocked.*

Turn upside down & start blending, then turn right-side up again so your ingredients hit the blades at full speed.

## A MODE FOR EVERY MOOD



**Blend Mode**  
*Perfect for smoothies, shakes & mixed drinks.*

Press power button once to start a 20-second blend cycle, or press it again to stop mid-cycle.



**Pulse Mode**  
*Perfect for guacamole, salsa & hummus.*

To enter Pulse Mode, double-press power button. Blue lights will flash left to right 3 times & the swirl will stay illuminated while Pulse Mode is active. Press & hold power button repeatedly to pulse. Pulse Mode will end after 5 seconds of inactivity.



**Lock Mode**  
*Perfect for sipping & travel.*

**To lock**, you must be in Blend Mode. Secure lid, then hold down power button until purple circle flashes 3 times.  
**To unlock**, hold down power button until blue circle flashes 3 times.